

Manual Time Set

When setting Unikon Clocks manually you should follow the following procedure.

1) Insert the power in to the ring marker

A red light will appear and the amber light will start to flash, be patient and wait for the red, and green to start flashing, it may take a minute.

2) Present the security token and then connect the Unikon base and printer as normal.

3) If there is no radio clock signal you will see the following message

'NO RADIO CLOCK TIME'

Switch off club system and try again'

C: Set clock manually

Press C

You will now have screen displaying the following

1 Set Clock Manually

2 Use Current Time

Underneath will be the day and time

Tu 02/07/13 10-23-12

Telephone TIM 123 and check that the date and time is correct. If the running time is correct simply press number 2 on the key pad and this will select 'Use Current time'

Should the running time be out press number 1 on the keypad to select Set clock manually'

You will now see a screen with the date flashing.

To set the time use the numeric keys on the key pad to set it to the correct time

When you have set the time correct press the green/OK button

The next screen will give you the option to Set by pressing OK or Exit by pressing C

If the time is okay press the Green/OK button

All this sounds a lot but in reality will only take a couple of minutes.

For details of MSF signal outages please visit the NPL website

<http://www.npl.co.uk/science-technology/time-frequency/products-and-services/time/msf-outages>